

IE MK5 & MK6 TSI Cold Air Intake (IEINCC2 & IEINCC3) Install Guide

This guide will walk you through the installation of the IEINCC2 and IEINCC3 cold air intake kit for the MK5/MK6 2.0T TSI engines. This can be installed on a completely stock car and does not require any additional parts to do so. We recommend having a qualified professional install this intake kit. Integrated Engineering is not responsible for any damage caused by incorrect installation.

Required tools:

- Socket Wrench
- 7mm socket
- Torx T25
- 8mm triple square
- Phillips screwdriver
- Hose clamp tool or pliers
- Small flat head screwdriver (optional)

Kit contents:

- 1X Heat shield & velocity stack assembly
- 1X 5" high-flow filter & clamp
- 1X Intake tube
- 1X Intake tube to turbo coupler
- 1X intake tube to MAF coupler
- 1X MAF to velocity stack coupler
- 6X coupler hose clamps

Before you begin:

Park your car on level surface and apply the parking brake or rack your car on a auto lift. It is also recommended to allow the car to cool before beginning this install procedure.

Open your IE Cold Air Intake Kit, inspect all components, and verify their quantities.



Removing the factory air ducting to the airbox. Remove the Torx T25 screws that holds the duct to the radiator support. There will be one on each side of the air duct.



Unclip the plastic lid on the air duct.



Remove the air duct from the car.




Unplug mass airflow sensor (MAF).



Using a hose clamp tool or pliers, remove the spring clip that holds the inlet pipe to the MAF. The clamp can be moved onto the pipe behind the MAF. Remove hose from MAF.



Remove Torx T25 bolt securing the back of the airbox. Pull straight up to remove airbox. *Note: If your car is equipped with secondary air injection (SAI), unclip the plastic hose before removing airbox.*




Remove the two Torx phillips screws holding the MAF to the airbox. Slide the MAF out and carefully set it aside. This will be reused later



Remove the inlet pipe mount bolt from the bracket using an 8mm triple square.



Using a hose clamp or pliers, loosen the lower clamp on the inlet pipe to turbo coupler. Pull the inlet pipe up slightly to allow access to the rear breather.




Carefully unclip the rear breather to remove from inlet pipe. Once this has been removed, the inlet pipe can be removed from the car.



Loosely install the smallest reducing coupler onto the IE inlet pipe. Slide a 50-70mm clamp and 70-90mm clamp onto the coupler. *Note: Do not tighten clamps in this step.*



Push coupler onto the inlet of the turbocharger, confirming that the coupler is on entirely. Tighten lower hose clamp only with a 7mm socket.



Reinstall the factory 8mm triple square bolt through the IE inlet pipe mount tab to the heat shield.



Clip the rear breather hose onto the machined barb on IE inlet pipe. It is suggested to lightly lubricate the o ring to aid installation.




If you do not have SAI, skip forward three steps. Install the SAI breather filter to SAI adapter and tighten included clamp.




Push clip to install the IE SAI filter and adapter to the factory SAI hose.




Use the included ziptie to securely mount the SAI hose away and hidden. Make sure the location is free from any moving shifter linkage or hot coolant lines.




Line up the IE rubber grommets on the heat shield with the factory mount points.



Install heat shield onto the two mount posts in the engine bay by pressing down above the grommets to fully seat them.



Install the straight reducing coupler onto the open end of the inlet pipe with the larger end facing forward. Install 70-90mm clamps on both ends of this coupler. *Note: Do not tighten clamps in this step.*




Plug in MAF sensor.



Slide MAF into coupler with the arrow facing backward. This is VERY important, as the car will not operate unless it is installed properly. We recommend installing the MAF with the wiring on the bottom side as a visual preference.



Install large elbow coupler and 80-100mm clamp between velocity stack and MAF.



Ensure everything sits in place, relaxed, and without tension. Once you are happy with the intake position, firmly tighten all the hose clamps.



Install the air filter and included clamp onto the velocity stack.



Rotate air filter so IE logo is facing upward. Tighten clamp firmly to velocity stack.



Verify all bolts, nuts, and harness clips are installed and tightened, all hose clamp connections are tight, and that your heat shield is fully installed. Start the car and inspect for any leaks or rubbing components. Enjoy the performance, looks, and sound of your new IE Cold Air Intake!



Thank you for purchasing another Integrated Engineering product. We are dedicated to serving your VW/Audi engine and performance needs. Please check our website frequently for new product releases. If you have any questions or concerns about this product please do not hesitate to contact us.

Integrated Engineering

801.484.2021

sales@performancebyie.com

www.performancebyie.com

PERFORMANCE BY



